


LW-MODL-PT5A Quick Start Guide



Input Neutral →
 Input Ground →
 Input Hot Line →

← Output Neutral
 ← Output Ground
 ← Output Hot Line

